



Complete unipolar breaker 400/630.

mark	designation	400		630	
		code	brisch nr	code	brisch nr
	complete breaker RUBC 96				
1	arc-blowout coil with suppor	60 113	38 442 025	60 114	38 442 027
2	coil core	60 101	61 680 004A	60 100	61 680 003A
3	fixed contact in copper fixed contact in silver	60 396 94 192	33 770 024 66 245 022	94 194	66 245 024
4	left and right pole part	60 102	63 653 007	60 102	63 653 007
see overleaf					
5	blowout cage	94 142	41 423 016	94 141	41 423 015
6	tubular rivet		02 117 316		02 117 316
7	cage bolt	60 110	67 752 022D	60 110	67 752 022D
8	moving arc-blowout horn	94 018	35 341 006	94 018	35 341 006

unipolar breaker RUBC 96 range 400 up to 630

mark	designation	400		630	
		code	brisch nr	code	brisch nr
9	moving contact in copper	60 397	33 770 021		
	moving contact in silver	94 193	66 245 023	94 195	66 245 025
10	pin support	60 105	63 665 005	60 105	63 665 005
11	spring guide	60 107	33 373 006	60 107	33 373 006
12	contact spring	94 173	65 812 006	94 175	65 813 001
13	spring bearing	60 106	33 521 001	60 106	33 521 001
14	moving pin lever	60 104	35 780 068	60 104	35 780 068
15	spring	94 074	35 824 007	94 074	35 824 007
16	spring support	60 399	35 561 077	60 399	35 561 077
17	for closing coil, see on chart (sheets nr 10.19)				
18	armature	60 400	36 554 031	60 400	36 554 031
19	axis	60 401	70 000 015	60 401	70 000 015
20	shunt support	60 402	70 000 019	60 402	70 000 019
21	supple connection	60 403	70 000 021	60 403	70 000 021
22	moving frame	60 405	36 551 010	60 405	36 551 010
23	armature support	60 406	70 000 020	60 406	70 000 020
24	plate		33 171 500		33 171 500
	complete kit of insulating parts for one pole	60 115		60 116	
	complete kit for one pole RUBC contact in copper (references nr 3-8-9 and 12 are included)	60 398			
	complete kit for one pole RUBC contact in silver (references nr 3-8-9 and 12 are included)	94 203	84 850 009	94 204	84 850 010