



Complete unipolar contactor 80/200.

		80		150		200	
mark	designation	code	brisch nr	code	brisch nr	code	brisch nr
	complete unipolar contactor CBC 57						
1	arc-blowout coil	94 136	38 442 013	60 166	38 442 015	94 138	38 442 017
	arc-blowout coil (wire type) 10 A	94 132	38 434 004				
	arc-blowout coil (wire type) 16 A	94 133	39 010 559				
	arc-blowout coil (wire type) 25 A	94 134	38 434 005				
	arc-blowout coil (wire type) 40 A	94 135	38 434 579				
2	fixed contact in silver	94 106	36 241 019	94 114	36 243 012	94 115	36 243 013
	fixed contact in copper			94 027	35 623 010	94 028	35 623 511
3	moving contact in silver	94 105	36 241 018	94 117	36 243 016	94 118	36 243 017
	moving contact in copper			94 030	35 628 002	94 038	35 628 547
4	blowout cage (asbestos free)	94 139	41 423 013	94 148	41 423 031	94 147	41 423 030

see overleaf

unipolar contactor CBC 57 range 80 up to 200

mark	designation	80		150		200	
		code	brisch nr	code	brisch nr	code	brisch nr
5	eight-sided spring guide	94 040	35 651 078	94 040	35 651 078	94 040	35 651 078
6	contact spring	60 377	35 812 009	60 378	35 812 010	94 053	35 812 011
7	round spring guide	94 042	35 731 004	94 042	35 731 004	94 042	35 731 004
8	spring key	60 158	33 617 002	60 159	33 617 001	60 159	33 617 001
9	for closing coil, see on chart (sheets nr 10.08-10.09-10.10)						
10	return spring	94 066	35 822 001	94 068	35 822 003	94 071	35 823 002
11	brake washer for coil	94 081	35 847 024	94 083	35 847 027	94 082	35 847 025
12	supple connection	94 169	44 850 082	94 181	66 113 006	94 170	44 850 083
13	articulation screw	60 164	32 225 002	60 164	32 225 002	60 165	32 225 001
	complete kit for one pole contact in silver	94 155	44 850 018	94 157	44 850 020	94 162	44 850 033
	complete kit for one pole contact in copper			94 156	44 850 019	94 171	44 850 515