



Complete rupturing pole 500 direct current.

mark	designation	code	brisch nr
	complete rupturing pole 500	90 146	
1	compression spring	94 063	35 816 005
2	spring bearing top and bottom	60 135	31 710 015A
3	left and right pole part	60 102	63 653 007
4	coil core 500 A	60 100	61 680 003A
5	arc-blowout coil 500 A DC	60 114	38 442 027
6	blowout cage 500 A	94 141	41 423 015
7	roller	60 134	31 516 047
8	fixed contact in silver 500 A	94 194	66 245 024
9	moving arc-blowout horn	94 018	35 341 006
10	moving contact in silver 500 A	94 195	66 245 025

see overleaf

## rupturing pole 500 direct current CBC-CEX 71 1250 up to 2000

mark	designation	code	brisch nr
11	opening lever	60 143	64 110 013
12	supple connection	60 141	36 113 218
13	lever support	60 142	33 570 014
14	articulation support	60 140	36 540 015
15	special screw	60 139	34 185 004
16	lever support	60 133	34 271 001
17	cage bolt	60 110	67 752 022D
18	tubular rivet		02 117 316
	complete kit of insulating parts for one rupturing pole 500/630	60 116	