



Complete pole 4500/6000.

mark	designation	4500	5000
		code	code
1	coil core	60 225	60 225
2	insulating pipe	60 370	60 370
3	fixed blow-out horn	94 016	94 016
4	blow-out coil	60 224	60 224
5	blow-out cage	94 143	94 143
6	moving blow-out horn	94 019	94 019
7	moving contact pin for CBC	94 119	94 119
	moving contact pin for CMA	94 119E	94 119E
8	contact spring	94 062	94 062
9	moving contact pin support	60 229	60 229

see overleaf

pole 4500/6000 CBC-CMA 1200 V ===

mark	designation	4500	5000
		code	code
10	moving support	60 228	60 228
11	axis	60 230	60 230
12	upper shunt tip	60 231	60 231
13	fixed contact pin	94 120	94 120
14	lower contact	60 523	60 523
15	intermediary lower contact	60 232	60 232
16	upper shunt	94 178*	94 178*
	lower shunt	94 179	94 179
17	tightening plate	60 365	60 365
18	protecting insulator	60 366	60 366
19	set of bars for series-connection	60 500	60 500
20	upper contact of pole	60 512	60 512
21	upper contact of pole	60 226	60 226
	complete kit of contacts for 1 pole CBC including fixed and moving contacts, moving blow-out horns and compression springs	60 602	60 602
	complete kit of contacts for 1 pole CMA including fixed and moving contacts, moving blow-out horns and compression springs	60 602 E	60 602 E
	kit of insulating parts for one pole	8	60 622