



Complete rupturing pole 500 direct current.

| mark | designation | code | brisch nr |
|------|-------------------------------|--------|-------------|
| | complete rupturing pole 500 | 90 147 | |
| 1 | fixed contact in silver 500 A | 94 194 | 66 245 024 |
| 2 | coil core | 60 100 | 61 680 003A |
| 3 | left and right insulated bar | 60 147 | 66 783 090 |
| 4 | arc-blowout coil 500 A DC | 60 114 | 38 442 027 |
| 5 | left and right pole part | 60 102 | 63 653 007 |
| 6 | blowout cage 500 A | 94 141 | 41 423 015 |
| 7 | roller | 60 134 | 31 516 047 |
| 8 | tubular rivet | | 02 117 316 |
| 9 | cage bolt | 60 110 | 67 752 022D |
| 10 | moving arc-blowout horn | 94 018 | 35 341 006 |

see overleaf

rupturing pole 500 direct current CBC-CEX 2500 up to 5000

| mark | designation | code | brisch nr |
|-------------|---|-------------|------------------|
| 11 | moving contact in silver 500 A | 94 195 | 66 245 025 |
| 12 | opening lever | 60 144 | 33 218 071 |
| 13 | supple connection | 60 148 | 36 113 219 |
| 14 | lever support | 60 145 | 33 665 016 |
| 15 | articulation support | 60 149 | 36 540 016 |
| 16 | shunt support | 60 146 | 33 375 121 |
| 17 | special screw | 60 139 | 34 185 004 |
| 18 | lever support | 60 133 | 34 271 001 |
| 19 | compression spring | 94 063 | 35 816 005 |
| 20 | spring bearing top and bottom | 60 135 | 31 710 015A |
| | complete kit of insulating parts for one rupturing pole 500/630 | 60 116 | |