



Complete rupturing pole 200.

mark	designation	code	brisch nr
	complete rupturing pole 200 - copper contact	90 058	44 543 034
	complete rupturing pole 200 - silver contact	90 058M	
1	support bar	60 185	37 733 002
2	arc-blowout coil 200 A	94 138	38 442 017
3	insulating washer	60 174	37 211 001
4	right pole part	60 154	35 780 053
5	blowout cage 200 A	94 146	41 423 029
6	moving contact in copper 200 A	94 036	35 628 012
7	supple connection	94 087	36 111 002
8	control lever		35 215 005
9	articulation plate	60 183	

see overleaf

## rupturing pole 200 CBA-CBC-CBFC-CBPA-CEX

mark	designation	code	brisch nr
10	compression spring	94 058	35 812 017
11	articulation lever	60 187	36 554 022
12	left pole part	60 157	35 780 052
13	fixed contact in copper 200 A	94 023	35 623 002
14	support for fixed contact	60 186	34 411 018
15	coil core	60 151	31 680 002
16	insulating pipe	60 171	37 244 010
	complete kit for one rupturing pole 200 copper contact (references 6 and 13 are included)	94 163	44 850 034
	complete kit for one rupturing pole 200 silver contact (references 6 and 13 are included)	94 163M	